

CN100 EPAL Coil nailer					
NO.	CODE	Description	NO.	CODE	Description
1	610800	BOLT M6×55	51	320630	FEED PISTON CAP
2	322970	SIDE PROTECTOR	52	630050	SNAP RING 26
3	322980	EXHAUST FILTER	53	621130	SAFETY SPRING
4	610060	BOLT M5X10 (Loctite)	54	326460	SAFETY
5	322990	EXHAUST COVER	55	110460	BODY
6	110450	CYLINDER CAP	56	640180	ROLL PIN 3X30
7	520320	GASKET	57	512210	O-RING 11×1.8
8	410670	PISTON STOP	58	423830	TRIGGER VALVE SEAT
9	621060	COMPRESSION SPRING	59	420080	TRIGGER VALVE CAP
10	511150	O-RING 56.5X3	60	320110	TRIGGER STEM
11	323000	HEAD VALVE WASHER	61	510030	O-RING 2.5X1.4
12	310560	HEAD VALVE PISTON	62	622940	TRIGGER VALVE SPRING
13	511160	O-RING 69X3.2	63	423840	TRIGGER VALVE BUSHING
14	512900	O-RING 60X5.3	64	511850	O-RING 8.8×1.9
15	310570	MAIN PISTON	65	510180	O-RING 5.8X1.9
16	511170	O-RING 55.6X5.7	66	512680	O-RING 6.8X1.9
17	326450	DRIVER BLADE	67	640250	STRAIGHT PIN B3X15
18	311480	CYLINDER	68	423820	TRIGGER VALVE CAGE
19	511180	O-RING 72X3.2	69	510410	O-RING 18.3X2.65
20	511190	O-RING 70X5.7	70	512070	O-RING 15.8X1.9
21	310590	CYLINDER RING	71	320620	SAFETY BRACKET
22	511410	O-RING 108X3.5	72	320570	TRIGGER
23	410690	BUMPER	73	320560	CONTACT PLATE
24	621080	CHECK PAWL SPRING	74	640340	SPIRAL PIN 3X16
25	210060	CHECK PAWL	75	410140	HANDLE GRIP
26	323020	STEP PIN	77	511230	O-RING 45X3.2
27	420170	PIN CAP (A)	78	110470	END CAP
28	211950	DOOR	79	421540	MAGAZINE COVER
29	420160	PIN CAP (B)	80	420520	SPRING HOLDER (A)
30	623030	SPRING	81	620290	MAGAZINE SPRING
31	210270	LATCH	82	323090	NAIL SUPPORT PLATE
32	320990	DOOR LATCH PIN	83	420830	MAGAZINE POST
33	211960	NOSE	84	421550	MAGAZINE
34	323030	DOOR PIN	85	323100	STEP PIN
35	610510	BOLT M10X30 (Loctite)	86	410160	PLASTIC WASHER
36	511210	O-RING 76.5X2.6	87	630290	SNAP RING
37	510220	O-RING 6.7×1.8	88	420240	SPRING HOLDER (B)
38	320670	DUST COVER WASHES	89	630030	PLAIN WASHER
39	421530	GUARD COVER	90	410060	RUBBER BUTTON
40	610330	NUT M6(Nylock)	91	422660	GUARD COVER
41	210920	FEED PAWL	92	610550	BOLT M6X5
42	621090	FEED SPRING (A)	93	630070	SPRING SEAT
43	621100	FEED SPRING (B)	94	420640	PIN CAP C
44	510320	O-RING 10X2.65	95	324520	TRIGGER SLEEVE
45	323040	FEED PAWL PIN	97	311490	GASKET
46	323050	FEED PISTON	98	610250	BOLT M6X40
47	510440	O-RING 20.8X2.4	99	610240	BOLT M6X35
48	621110	FEED PISTON SPRING (A)			
49	621120	FEED PISTON SPRING (B)	P1	D326451	DRIVER UNIT
50	410150	FEED PISTON BUMPER	P2	T420091	TRIGGER VALVE

CN100 EPAL

